

580

### EXHAUST SYSTEM

#### **MASTER INDEX**


MASIER INDEX		OBOUR II	
INTERCOLUCTION PLOSE	PAGES	GROUP K	
INTRODUCTION PAGES ALPHABETICAL INDEX ENGINE ENGINE ENGINE ENGINE ENGINE ENGINE GEARBOX GEARBOX GEARBOX TRANSFER BOX TRANSFER BOX AXLES AND SUSPENSION STEERING VEHICLE AND ENGINE CONTROLS BRAKES FUEL SYSTEM AND AIR CLEANER EXHAUST SYSTEM COOLING/HEATING COOLING/HEATING COOLING/HEATING	PAGES 1 - 7 8 - 16 17 - 66 67 - 119 120 - 166 167 - 209 210 - 245 246 - 299 300 - 326 327 - 344 345 - 359 360 - 378 379 - 397 398 - 444 445 - 471 472 - 486 487 - 517 518 - 579 580 - 593 594 - 637 638 - 641 642 - 649 650 - 655	EXHAUST SYSTEM  EXHAUST SYSTEM  FRONT - 4 CYL PETROL & NAT ASP DIESEL FRONT - V8  REAR - PETROL AND NAT ASP DIESEL FRONT - DIESEL TURBO REAR - DIESEL TURBO FRONT - TDI REAR - TDI REAR - 200TDI	581 - 582 583 - 584 585 - 586 587 - 589 590 591 592 593
COOLING/HEATING BODY ELECTRICAL BODY AND CHASSIS INTERIOR TRIM	656 - 666 667 - 740 741 - 909 910 - 955		
SEATS STOWAGE ACCESSORIES - PAINTS NUMERICAL INDEX	956 - 1036 1037 - 1046 1047 - 1074 1076 - 1151		





581

### EXHAUST SYSTEM



Model DEFENDER 110 1987 onwards
Page AFKXAA1A

#### EXHAUST SYSTEM - FRONT - 4 CYL PETROL & NAT ASP DIESEL


III.	Part No.	Description	Qty	Remarks
1	NTC1794K	Downpipe	1	Petrol
	NTC1793K	Downpipe	1	Diesel
	ESR1617	Downpipe	1	Upto JA911705 Diesel From JA911706
2 3	ETC5337	Gasket exhaust	1	TIONE JASTI706
3	AFU2778	Nut	3	
4	NTC1030	Olive	1	
5	NRC7778	Bracket mounting	1	
6	NRC6467	Clamp exhaust	1	Upto 290071
_	90575748	Clamp exhaust	1	From 290072
7	NRC6466	U bolt	1	Upto 290071
	NRC6374	U bolt	1	From 290072
8	WL108001L	Washer spring	2	
9	FN108041L	Nut	2	
10	SH108701L	Bolt	1	
	WP105L	Washer plain	2	
12	NRC5403	Spacer	1	
13	572166	Bush rubber	2	
	572168	Washer plain	1	
	572167	Bush rubber	1	
	WL108001L	Washer spring	1	
18	FN108041L	Nut	1	
_		Heatshield exhaust	1	
			2	
			4	
22			4	
22	FN108041L	Nut	4	





582

### EXHAUST SYSTEM



Model DEFENDER 110 1987 onwards
Page AFKXAA1A

#### EXHAUST SYSTEM - FRONT - 4 CYL PETROL & NAT ASP DIESEL

III.	Part No.	Description	Qty	Remarks	
24 25	NTC4580 NTC4586 BH108131L WC112081L	Bracket support Clamp exhaust Bolt Washer plain	1 1 2 1	)From EA290072 )Upto EA338367 )and )From FA405333 )onwards	






583

#### **EXHAUST SYSTEM**

Model Page DEFENDER 110 1987 onwards

e AFKXAA2A

#### EXHAUST SYSTEM - FRONT - V8







584

#### EXHAUST SYSTEM

Model

DEFENDER 110 1987 onwards

Page AFKXAA2A

, 11 10 0 b 112/1

#### **EXHAUST SYSTEM - FRONT - V8**

23 22 17 19 18 21 19 17 19 17 16 18 21 17 18 19 17 16 18 17 18 19 17 18 19 17 16 18 19 10 10 11 10 10 10 10 10 10 10
--


III.	Part No.	Description	Qty Remarks
25 26 27	NRC9724 NRC9722 FS108201L WL108001L FN108041L	Heatshield exhaust Pipe Clip Screw Washer spring Nut	2 4 8 8 8





585

### **EXHAUST SYSTEM**



Model DEFENDER 110 1987 onwards
Page AFKXAA3A

#### EXHAUST SYSTEM - REAR - PETROL AND NAT ASP DIESEL


Ш	. Part No.	Description	Qty	Remarks
11 12	WL108001L FN108041L NRC7608 NRC7609 WL108001L FN108041L SH108701 WP105L NRC5403 572166	Silencer exhaust Olive Silencer exhaust Silencer exhaust Silencer exhaust Silencer exhaust Finisher tailpipe Bolt flanged Washer spring Nut Clamp exhaust U bolt Spring Washer Nut Bolt Washer plain Spacer Bush rubber Washer plain	1 1 1 1 1 6 6 6 2 2 4 4 2 4 4 2 4 4	Front Note(1) Note(2) Note(3) Note(4)





586

#### EXHAUST SYSTEM



DEFENDER 110 1987 onwards Model

AFKXAA3A Page

#### EXHAUST SYSTEM - REAR - PETROL AND NAT ASP DIESEL

III. Part No.	Description	<b>Qty Remarks</b>
17 572167 18 WL108001L 19 FN108041L	Bush rubber Washer spring Nut	2 2 2
Defender 130 RRC4419	Pipe exhaust extension	1

Note(1) Note(2) Note(3) Note(4)


Rear - single can Rear - single can - Australia Rear - twin can - Option and Switzerland HCPU and Germany





587

### EXHAUST SYSTEM



Model DEFENDER 110 1987 onwards
Page AFKXDC1A

#### **EXHAUST SYSTEM - FRONT - DIESEL TURBO**


III.	Part No.	Description	Qty	Remarks
1	NTC4426	Downpipe	1	Upto VIN 450078
	ESR159	Downpipe	1	From VIN 450079
2	NTC3608	Clamp exhaust	1	
3	ESR266	Bracket mounting	1	From VIN 450079
Fix	ings - downpipe to e	ngine		
	SH110161	Screw	1	Upto VIN 450078
	WA110061	Washer plain	1	Upto VIN 450078
Fix	ings - bracket to dov	vnpipe		
	S\$106161L	Screw	2	From VIN 450079
5	WJ106001L	Washer plain	2	From VIN 450079
Fix	ings - bracket to eng	ine		
6	S\$108161L	Screw	1	From VIN 450079
7	WA108051L	Washer plain	1	From VIN 450079
8	SH110141L	Screw	1	From VIN 450079
9	WA110061L	Washer plain	1	From VIN 450079
	NTC4833	Heatshield exhaust	1	
11	NTC4548	Bracket support	1	Upto VIN FA418948
	ESR219	Bracket support	1	From VIN FA418949
		- I - I		





588

#### **EXHAUST SYSTEM**



Model DEFENDER 110 1987 onwards
Page AFKXDC1A

#### EXHAUST SYSTEM - FRONT - DIESEL TURBO

Description

		,	
Fixings - heats 12 F\$106167L F\$106167L 13 WA106041L WA106041L	shield to bracket Screw Screw Washer plain Washer plain	2 1 2 1	Note(1)) Note(1) Upto VIN FA418948 From VIN FA418949
Fixings - brack	ket to waste gate		
14 FS106167L	Screw	1	Note(1)
15 WL106001	Washer spring	1	
16 NH106041L	Nut	1	
Fixings - heats	shield to stud		
17 SĤ108141L	Screw	1	Note(1)
18 WJ108001	Washer plain	2	(-)
19 NTC4221	Pipe exhaust intermedia	ate 1	
20 NTC1030	Olive	1	
21 BH108091L	Bolt	3	
22 WL108001L	Washer spring	3	
23 FN108041L	Nut	3	


**Qty Remarks** 





589

#### **EXHAUST SYSTEM**



Model DEFENDER 110 1987 onwards
Page AFKXDC1A

#### EXHAUST SYSTEM - FRONT - DIESEL TURBO

24       NTC5205       Heatshield slave cylinder       1         25       NTC2278       Clamp exhaust       2         26       FS108207L       Screw       4         27       WL108001L       Washer spring       4         28       FN108041L       Nut       4         29       ESR169       Bracket mounting       1	arks
29 ESR169       Bracket mounting       1         30 90575748       Clamp exhaust       1         31 NRC6374       U bolt       1         32 WL108001L       Washer spring       2         33 FN108041L       Nut       2         34 BH108141L       Bolt       1         35 WP105L       Washer plain       2         36 NRC5403       Spacer       1         37 572166       Bush rubber       2         38 572168       Washer       2         39 572167       Bush rubber       1         40 WL108001L       Washer spring       1         41 FN108041L       Nut       1	


Note(1) Use Loctite 242 or similar





590

#### EXHAUST SYSTEM



Model DEFENDER 110 1987 onwards

Page AFKXDC2A

#### EXHAUST SYSTEM - REAR - DIESEL TURBO


III.	Part No.	Description	Qty	Remarks
1 2	NTC1666 NTC1030	Silencer exhaust Olive	1	Front
3 4	NTC2832 BH108091L	Silencer exhaust Bolt	i 6	Rear
5 6	WL108001L FN108041L	Washer spring Nut	6 6 2 2	
	NRC7608 NRC7609	Clamp exhaust U bolt		
	WL108001L FN108041L SH108701	Washer spring Nut Screw	4	
12	WP105L NRC5403	Washer Spacer	2 4 2	
14	572166 572168	Bush rubber Washer	4	
17	572167 WL108001L	Bush rubber Washer spring	2 2 2	
_	FN108041L	Nut	2	
Dei	fender 130 RRC4419	Pipe exhaust extension	1	





591

### **EXHAUST SYSTEM**



Model DEFENDER 110 1987 onwards
Page AFKXDE1A

#### EXHAUST SYSTEM - FRONT - TDI


1         ESR158 ESR2297         Downpipe Downpipe Non-Cat         1         Upto LA939975 From MA939976           2         ESR2739 ESR3495         Downpipe with cat         1         From MA939976           3         NTC3608         Clamp exhaust         1         Swiss only           4         ESR266 ESR3260         Bracket mounting         1         From MA939976           5         SS106161L Screw socket         2         From MA939976           6         WJ106001L Washer plain         2         From MA939976           7         SS108161L Screw socket         1         From MA939976           8         WA108051L Washer plain         2         From MA939976           9         SH110141L Screw socket         1         From MA939976           10         WA108051L Washer plain         2         From MA939976           10         WA108051L Washer plain         1         From MA939976           11         WA106061L Washer plain         1         From MA939976           12         SH1011L Washer plain         1         From MA939976           13         WJ108001 Washer plain         1         From MA939976           14         ESR219         Bracket support         1         From MA939976 <th>III.</th> <th>Part No.</th> <th>Description</th> <th>Qty</th> <th>Remarks</th>	III.	Part No.	Description	Qty	Remarks
ESR2297 Downpipe Non-Cat 1 From MA939976 ESR2739 Downpipe with cat 1 From MA939976 ESR3495 Downpipe with cat 1 Swiss only  NTC3608 Clamp exhaust 1 ESR266 Bracket mounting 1 ESR3260 Gasket exhaust 1 From MA939976 SS106161L Screw socket 2 WJ106001L Washer plain 2 SS108161L Screw socket 1 Washer plain 2 SH10141L Screw 1 Screw 1 Washer plain 2 WJ108001 Washer plain 2 WJ108001 Washer plain 2 WJ108001 Washer plain 2 WA106041L Washer plain 1 FRS106167L SCREW 1 WA106041L Washer spring 1 WH106041L Washer spring 1 WH106041L Nut 1 ESR208 Clamp exhaust 2 ESR208 Clamp exhaust 2 ESR208 Clamp exhaust 2 SCREW 4	1		Downpipe	1	Unto FA030075
ESR2739		ESR2297	Downpipe Non-Cat	i	
ESR3495 Downpipe with cat 1 Swiss only  NTC3608 Clamp exhaust 1  ESR266 Bracket mounting 1  ESR3260 Gasket exhaust 1 From MA939976  SS106161L Screw socket 2  WJ106001L Washer plain 2  SS108161L Screw socket 1  WA108051L Washer plain 1  SCREW SOCKET 1  WA110061L Washer plain 1  NTC4833 Heatshield 1  NTC4833 Heatshield 1  SCREW 1  WJ108001 Washer plain 2  SH108141L Screw 1  WA108001 Washer plain 2  HESR219 Bracket support 1  SCREW 1  WA106041L Washer plain 1  FRS106167L SCREW 1  WA106001 Washer plain 1  NH106001 Washer spring 1  NH106001 Washer spring 1  NH106041L Nut 1  ESR361 Heatshield 1  ESR208 Clamp exhaust 2  ESR361 Heatshield 1  ESR208 Clamp exhaust 2  SCREW 4  WL108001L Washer spring 4	2		Downpipe with cat	1	
STC3608			Downpipe with cat	1	
4       ESR266 ESR3260       Bracket mounting Gasket exhaust       1       From MA939976         5       SS106161L WJ106001L Screw socket       2       From MA939976         6       WJ106001L Washer plain       2       From MA939976         7       SS108161L Screw socket       1       1         8       WA108051L Washer plain       1       1         9       SH110141L Screw       1       1         10       WA110061L Washer plain       1       1         11       NTC4833 Heatshield       1       1         12       SH108141L Screw       1       1         13       WJ108001 Washer plain       2       1         14       ESR219 Bracket support       1       1         15       FS106167L Washer plain       1       1         16       WA106041L Washer spring       1       1         17       FS106167L Washer spring       1       1         18       WL106001 Washer spring       1       1         19       NH106041L Nut       1       1         20       ESR361 Heatshield       1       1         21       ESR208 Clamp exhaust       2         22       FS1082			Clamp exhaust	1	Omeo omy
ESR3260 Gasket exhaust 1 From MA939976  5 SS106161L Screw socket 2  6 WJ106001L Washer plain 2  7 SS108161L Screw socket 1  8 WA108051L Washer plain 1  9 SH110141L Screw 1  10 WA110061L Washer plain 1  11 NTC4833 Heatshield 1  12 SH108141L Screw 1  13 WJ108001 Washer plain 2  14 ESR219 Bracket support 1  15 FS106167L Screw 1  16 WA106041L Washer plain 1  17 FS106167L Screw 1  18 WL106001 Washer spring 1  19 NH106041L Nut 1  20 ESR361 Heatshield 1  21 ESR208 Clamp exhaust 2  22 FS108251L Screw 4  23 WL108001L Washer spring 4	4			1	
5       SS106161L       Screw socket       2         6       WJ106001L       Washer plain       2         7       SS108161L       Screw socket       1         8       WA108051L       Washer plain       1         9       SH110141L       Screw       1         10       WA110061L       Washer plain       1         11       NTC4833       Heatshield       1         12       SH108141L       Screw       1         13       WJ108001       Washer plain       2         14       ESR219       Bracket support       1         15       FS106167L       Screw       1         16       WA106041L       Washer plain       1         17       FS106167L       Screw       1         18       WL106001       Washer spring       1         19       NH106041L       Nut       1         20       ESR361       Heatshield       1         21       ESR208       Clamp exhaust       2         22       FS108251L       Screw       4         23       WL108001L       Washer spring       4	_		Gasket exhaust	1	From MA939976
7       SS108161L       Screw socket       1         8       WA108051L       Washer plain       1         9       SH110141L       Screw       1         10       WA110061L       Washer plain       1         11       NTC4833       Heatshield       1         12       SH108141L       Screw       1         13       WJ108001       Washer plain       2         14       ESR219       Bracket support       1         15       FS106167L       Screw       1         16       WA106041L       Washer plain       1         17       FS106167L       Screw       1         18       WL106001       Washer spring       1         19       NH106041L       Nut       1         20       ESR361       Heatshield       1         21       ESR208       Clamp exhaust       2         22       FS108251L       Screw       4         23       WL108001L       Washer spring       4	5				
7       SS108161L       Screw socket       1         8       WA108051L       Washer plain       1         9       SH110141L       Screw       1         10       WA110061L       Washer plain       1         11       NTC4833       Heatshield       1         12       SH108141L       Screw       1         13       WJ108001       Washer plain       2         14       ESR219       Bracket support       1         15       FS106167L       Screw       1         16       WA106041L       Washer plain       1         17       FS106167L       Screw       1         18       WL106001       Washer spring       1         19       NH106041L       Nut       1         20       ESR361       Heatshield       1         21       ESR208       Clamp exhaust       2         22       FS108251L       Screw       4         23       WL108001L       Washer spring       4			Washer plain	2	
9 SH110141L Screw 1 10 WA110061L Washer plain 1 11 NTC4833 Heatshield 1 12 SH108141L Screw 1 13 WJ108001 Washer plain 2 14 ESR219 Bracket support 1 15 FS106167L Screw 1 16 WA106041L Washer plain 1 17 FS106167L Screw 1 18 WL106001 Washer spring 1 19 NH106041L Nut 1 20 ESR361 Heatshield 1 21 ESR208 Clamp exhaust 2 22 FS108251L Screw 4 23 WL108001L Washer spring 4		SS108161L	Screw socket	1	
10       WA110061L       Washer plain       1         11       NTC4833       Heatshield       1         12       SH108141L       Screw       1         13       WJ108001       Washer plain       2         14       ESR219       Bracket support       1         15       FS106167L       Screw       1         16       WA106041L       Washer plain       1         17       FS106167L       Screw       1         18       WL106001       Washer spring       1         19       NH106041L       Nut       1         20       ESR361       Heatshield       1         21       ESR208       Clamp exhaust       2         22       FS108251L       Screw       4         23       WL108001L       Washer spring       4		WA108051L	Washer plain	1	
11 NTC4833       Heatshield       1         12 SH108141L       Screw       1         13 WJ108001       Washer plain       2         14 ESR219       Bracket support       1         15 FS106167L       Screw       1         16 WA106041L       Washer plain       1         17 FS106167L       Screw       1         18 WL106001       Washer spring       1         19 NH106041L       Nut       1         20 ESR361       Heatshield       1         21 ESR208       Clamp exhaust       2         22 FS108251L       Screw       4         23 WL108001L       Washer spring       4		SH110141L		1	
12       SH108141L       Screw       1         13       WJ108001       Washer plain       2         14       ESR219       Bracket support       1         15       FS106167L       Screw       1         16       WA106041L       Washer plain       1         17       FS106167L       Screw       1         18       WL106001       Washer spring       1         19       NH106041L       Nut       1         20       ESR361       Heatshield       1         21       ESR208       Clamp exhaust       2         22       FS108251L       Screw       4         23       WL108001L       Washer spring       4	10	WA110061L		1	
13       WJ108001       Washer plain       2         14       ESR219       Bracket support       1         15       FS106167L       Screw       1         16       WA106041L       Washer plain       1         17       FS106167L       Screw       1         18       WL106001       Washer spring       1         19       NH106041L       Nut       1         20       ESR361       Heatshield       1         21       ESR208       Clamp exhaust       2         22       FS108251L       Screw       4         23       WL108001L       Washer spring       4				1	
14 ESR219       Bracket support       1         15 FS106167L       Screw       1         16 WA106041L       Washer plain       1         17 FS106167L       Screw       1         18 WL106001       Washer spring       1         19 NH106041L       Nut       1         20 ESR361       Heatshield       1         21 ESR208       Clamp exhaust       2         22 FS108251L       Screw       4         23 WL108001L       Washer spring       4				1	
15 FS106167L Screw 1 16 WA106041L Washer plain 1 17 FS106167L Screw 1 18 WL106001 Washer spring 1 19 NH106041L Nut 1 20 ESR361 Heatshield 1 21 ESR208 Clamp exhaust 2 22 FS108251L Screw 4 23 WL108001L Washer spring 4			Washer plain	2	
16       WA106041L       Washer plain       1         17       FS106167L       Screw       1         18       WL106001       Washer spring       1         19       NH106041L       Nut       1         20       ESR361       Heatshield       1         21       ESR208       Clamp exhaust       2         22       FS108251L       Screw       4         23       WL108001L       Washer spring       4			Bracket support	1	
17       FS106167L       Screw       1         18       WL106001       Washer spring       1         19       NH106041L       Nut       1         20       ESR361       Heatshield       1         21       ESR208       Clamp exhaust       2         22       FS108251L       Screw       4         23       WL108001L       Washer spring       4	10	FS10010/L		1	
18       WL106001       Washer spring       1         19       NH106041L       Nut       1         20       ESR361       Heatshield       1         21       ESR208       Clamp exhaust       2         22       FS108251L       Screw       4         23       WL108001L       Washer spring       4	17	VVA106041L		1	
19 NH106041L Nut 1 20 ESR361 Heatshield 1 21 ESR208 Clamp exhaust 2 22 FS108251L Screw 4 23 WL108001L Washer spring 4				1	
20 ESR361       Heatshield       1         21 ESR208       Clamp exhaust       2         22 FS108251L       Screw       4         23 WL108001L       Washer spring       4				1	
21 ESR208       Clamp exhaust       2         22 FS108251L       Screw       4         23 WL108001L       Washer spring       4				1	
22 FS108251L Screw 4 23 WL108001L Washer spring 4				1	
23 WE108001L Washer spring 4			Clamp exhaust	2	
24 FN1000445	23		Screw	4	
et intouvers. Nut	24	FN100001L			
·	۷.4	TINTOUU4TL	inut .	4	





592

#### EXHAUST SYSTEM



Model DEFENDER 110 1987 onwards

Page AFKXDE2A

#### EXHAUST SYSTEM - REAR - TDI


III.	Part No.		Description		Qty	Remarks
Exc	cept Defen	der 130				
1	ESR54		Silencer exhaust		1	Upto LA939975
	ESR2383		Silencer exhaust		1	From MA939976
2	NV110041L		Nut		2	
	ESR414		Bracket mounting		1	Front Note(1)
	ESR2087		Bracket mounting		1	Front Note(2)
4			Mounting rubber		1	Upto LA939975
	NTC3650		Mounting rubber		1	From MA939976
5	ESR359		Tail pipe		1	Upto LA939975
	ESR2384		Tail pipe		1	From MA939976
	ESR1696		Tail pipe		1	Australia
			, ,			Upto LA939975
	ESR3152		Tail pipe		1	From MA939975
6	NV110041L		Nut		2	
7	ESR360		Bracket mounting	Inter	1	Note(1)
	ESR2215		Bracket mounting	Inter	1	Note(2)
	ESR3294		Bracket mounting	Inter	1	Note(3)
8			Screw		1	
	WP185L		Washer plain		2	
	NV108041L		Nut philidas		1	
11	NTC5582		Mounting rubber		1	Upto LA939975
	NTC3650		Mounting rubber		1	From MA939976
12	ESR95		Bracket mounting	Rear	1	Upto MA948144
	ESR3293		Bracket mounting	Rear	1	From MA948145
	FS108251L		Screw		1	
	WP185L		Washer plain		2	
	NV108041L		Nut philidas		1	
	NTC5582		Mounting rubber		1	
17	NTC2022		Finisher tail pipe		1	HCPU
Not	e(1)	Up to LA939	975			
	e(2)		976 UptoMA94814	4		
	e(3)	From MA948				





593

# EXHAUST SYSTEM



Model DEFENDER 110 1987 onwards
Page AFKXDE3A

#### EXHAUST SYSTEM - REAR - 200TDI

III. Part No.	Description	Qty	Remarks
Defender 13	0		
1 ESR255	Pipe extension	1	
ESR2386	Pipe extension	1	Upto LA939975
2 NV1100411	- Nut	2	From MA939976
3 ESR414	Bracket mounting		U-4- 1 40000==
ESR2087	Bracket mounting		Upto LA939975
4 NTC5582	Mounting rubber		From MA939976
NTC3650	Mounting rubber		Upto LA939975
5 ESR439	Silencer		From MA939976
ESR2385	Exhaust silencer main		Upto LA939975
6 NV110041L	- Nut	1	From MA939976
7 ESR359	Tail pipe	2	
ESR2384	Tail pipe	1	Upto LA939975
8 NV110041L	Nut	1	From MA939976
9 ESR360	Bracket mounting	2 1	
ESR2215	Bracket mounting		Note (1)
ESR3294	Bracket mounting	1	Note (2)
10 FS108251L	Screw	1	Note (3)
11 WP185L	Washer plain	1	
12 NV108041L	Nut philidas	2	
13 NTC5582	Mounting rubber		
NTC3650	Mounting rubber  Mounting rubber	1 1	Upto LA939975
14 ESR95	Bracket mounting	1 !	From MA939976
ESR3293	Bracket mounting	1 1	Jpto MA948144
15 FS108251L	Bracket mounting Screw	1 1	rom MA948145
16 WP185L	Washer plain	1	
17 NV108041L	Nut philidas	2	
18 NTC5582			
19 NTC2022	Mounting rubber	1	
, TOLOGE	Finisher tall pipe	1 +	HCPU
Note(1)	Up to LA939975		
Note(2)	From MA939976 UptoMA948144		
Note(3)	From MA948145		•





594

### COOLING/HEATING

#### MASTER INDEX

#### GROUP L

	PAGES	COOLING/HEATING	
INTRODUCTION PAGES	1 - 7	COOLING/HEATING	
ALPHABETICAL INDEX	8 - 16		
ENGINE	17 - 66	COOL MOSTERATING	
ENGINE	67 - 119	COOLING/HEATING	F00 F00
ENGINE	120 - 166	RADIATOR INTERCOLER & OV. COOLER COOLER	596 - 598
ENGINE	167 - 209	RADIATOR, INTERCOOLER & OIL COOLER - 300TDI	599 - 602
ENGINE	210 - 245	FAN COWL	603 - 604
ENGINE	246 - 299	RADIATOR A INTERCOCLER MODES	605 - 606
GEARBOX	300 - 326	RADIATOR & INTERCOOLER HOSES - 200TDI	607
GEARBOX	327 - 344	RADIATOR HOSES - V8	608 - 609
GEARBOX	345 - 359	OIL COOLER AND MOUNTING FRAME	610 - 611
TRANSFER BOX	360 - 378	COOLER AND FRAME - V8 LT77 GEARBOX	612
TRANSFER BOX	379 - 397	PIPES - NOTE(1)	613
AXLES AND SUSPENSION	398 - 444	PIPES	614
STEERING	445 - 471	PIPES - V8 - UPTO VIN FA429127	615 - 616
VEHICLE AND ENGINE CONTROLS	472 - 486	PIPES - V8 - FROM VIN FA429128	617
BRAKES	487 - 517	PIPES - V8 LT77 GEARBOX	618
FUEL SYSTEM AND AIR CLEANER	518 - 579	EXPANSION TANK	619 - 622
EXHAUST SYSTEM	580 - 593	HEATER COMPONENTS	623 - 625
COOLING/HEATING	594 - 637	HEATER COMPONENTS	626
COOLING/HEATING	638 - 641	HEATER CONTROLS	627 - 628
COOLING/HEATING	642 - 649	DEMISTERS AND OUTLET FLAPS	629
COOLING/HEATING	650 - 655	HEATER PIPES - 4 CYL PETROL 630 DIESEL	630
COOLING/HEATING	656 - 666	HEATER PIPES - 4 CYL PETROL 631 DIESEL	631
BODY ELECTRICAL	667 - 740	HEATER PIPES - V8	632
BODY AND CHASSIS	741 - 909	HEATER PIPES - 200TDI	633 - 634
INTERIOR TRIM	910 - 955	HEATER PIPES - 300TDI	635
SEATS	956 - 1036	CONDENSER - RHS/LHS	636
STOWAGE	1037 - 1046	EVAPORATOR ASSEMBLY - RHS	637
ACCESSORIES - PAINTS	1047 - 1074		
NUMERICAL INDEX	1076 - 1151		
· · · · · · · · · · · · · · · · · · ·			





595

### COOLING/HEATING

GROUP L

COOLING/HEATING

GROUP L

COOLING/HEATING


COOLING/HEATING FLUID SYSTEM - RHS FACIA PANEL ASSEMBLY - VACUUM PIPES & RESERVOIR - RHS/LHS HEATER PIPES - 4 CYLINDER - RHS  HEATER PIPES - 4 CYLINDER - RHS  FACIA PANEL ASSEMBLY - FRESH AIR DUCT - LHS HEATER CONTROLS - LHS PLENUM CHAMBER - LHS FACIA PANEL - LHS FACIA PANEL - LHS DEMISTER AND FLAPS	RHS 660 661
--	----------------





596

### COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXAA1A

#### COOLING SYSTEM - RADIATOR


III. Part No.	Description	<b>Qty Remarks</b>
2.5 Petrol		
1 ESR79	Radiator	1 Upto VIN FA389798
ESR77	Radiator	1 From VIN FA389981
ESR78	Radiator	1 Note(1)
		From VIN FA389799
E0D4077	Davida I.	Upto VIN JA919831
ESR1677	Radiator	1 Note(1)
		From VIN JA919832
V8 Petrol		
1 ESR76	Radiator	1 Upto VIN FA428918
ESR203	Radiator	1 From VIN FA428919
ESR204	Radiator	1 Note(1)
		From VIN FA429128
		Upto VIN JA922098
ESR1678	Radiator	1 Note(1)
		From VIN JA919099
Diesel		
1 ESR79	Radiator	1 Upto VIN FA389798
ESR77	Radiator	1 From VIN FA389981
ESR78	Radiator	1 Note(1)
		From VIN FA389799
		Upto VIN JA919831
ESR1677	Radiator	1 Note(1)
		From VIN JA919832





597

#### **COOLING/HEATING**



Model DEFENDER 110 1987 onwards
Page AFLXAA1A

#### COOLING SYSTEM - RADIATOR


III.	Part No.	Description	Qty	Remarks
1 1	liesel Turbo NTC6168	Radiator	1	Note(1)
1	<b>00Tdi</b> NTC4893 ESR1676	Radiator Radiator	1	Note(2) Upto VIN JA919831 Note(2) From VIN JA919832
2 3 4 5 6 7 8 9	NTC4609 NTC5171 KTP9024 RRO2125L RRO2126L NTC3858 572312 NRC5544	Filler plug Washer sealing Vent penthouse Washer Plug Adaptor Bush radiator mounting Bush radiator mounting	1 1 1 1 2 2	V8 Except V8 Diesel Turbo Lower Upper





598

#### COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXAA1A

#### **COOLING SYSTEM - RADIATOR**

Part No.	Description	Qty	Remarks
NRC4839	Bracket radiator LH	1	Upto 4/3/92
NRC8609	Bracket radiator RH	1	Upto 4/3/92
ESR69	Bracket radiator LH	1	From 5/3/92
ESR68	Bracket radiator RH	1	From 5/3/92
ESR282	Bracket radiator LH	1	200Tdi
ESR283	Bracket radiator RH	1	200Tdi
FS106201L	Flange screw	6	Upto 4/3/92
WC106041L	Washer plain	6	Upto 4/3/92
WL106001L		6	Upto 4/3/92
SH106207L	Screw	4	From 5/3/92
WC106047	Washer plain	4	From 5/3/92
SH106207L	Screw '	4	200Tdi
WC106047	Washer plain	4	200Tdi
ALR1982		1	From VIN JA910952
SH106207L	Screw	3	From VIN JA910952
WC106047	Washer plain	š	From VIN JA910952
	NRC8609 ESR69 ESR68 ESR282 ESR283 FS106201L WC106041L WL106001L SH106207L WC106047 SH106207L WC106047 ALR1982 SH106207L	NRC4839 Bracket radiator LH NRC8609 Bracket radiator RH ESR69 Bracket radiator LH ESR68 Bracket radiator RH ESR22 Bracket radiator LH ESR283 Bracket radiator RH FS106201L Flange screw WC106041L Washer plain WL106001L Screw WC106047 Washer plain SH106207L Screw WC106047 Screw WC106047 Screw WC106047 Screw SCREW WC106047 Screw SCREW SCREW WC106047 Screw SCREW SCREW WC106047 Screw SCR	NRC4839         Bracket radiator LH         1           NRC8609         Bracket radiator RH         1           ESR69         Bracket radiator LH         1           ESR68         Bracket radiator RH         1           ESR282         Bracket radiator LH         1           ESR283         Bracket radiator RH         1           FS106201L         Flange screw         6           WC106041L         Washer plain         6           WL106001L         Washer spring         6           SH106207L         Screw         4           WC106047         Washer plain         4           WC106047         Washer plain         4           WC106047         Washer plain         4           ALR1982         Bracket support         1           SH106207L         Screw         3

Note(1) Includes oil cooler for engine Includes oil cooler for engine and intercooler for turbo charger





599


#### **COOLING/HEATING**

Model Page DEFENDER 110 1987 onwards

•

AFLXAA1B









600

#### COOLING/HEATING


Model


DEFENDER 110 1987 onwards

Page

AFLXAA1C











601

### **COOLING/HEATING**

Model Page DEFENDER 110 1987 onwards


ļ

AFLXAA1D

#### COOLING SYSTEM - RADIATOR, INTERCOOLER & OIL COOLER - 300TDI

Remarks

III.	Part No.	Description	Qty
Int	ercooler hoses		
1	ESR2309	Hose intercooler/manifold	1
2	CN100608	Clip hose	1
	CN100708	Clip hose	1
	ESR2728	Pipe assy i'cooler/turbo	1
	ESR2055	Pipe intercooler/turbo	1
	ESR2119	Mounting rubber	1
7	ESR2120	Bracket mounting	1
3	ESR2729	Hose pipe/intercooler	1
	ESR2730	Hose turbo/pipe	1
10	CN100608	Clip hose	2
11	NY108041	Nut nyloc M8	1
12	SH108161	Screw M8	1
13	WA108041	Washer plain	i i
14	CN100608	Clip hose	ż







602


#### **COOLING/HEATING**

Model Page

DEFENDER 110 1987 onwards

AFLXAA1E










603

### COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXAA2A

#### COOLING SYSTEM - FAN COWL


III.	Part No.	Description	Qty	Remarks
2.5 1\	5 <b>Petrol</b> NRC3662 NTC3937	Cowl fan-radiator Cowl fan-radiator	1	Upto VIN FA389798 From VIN FA389799
<b>V</b> 8	Petrol NRC3406 NTC5685	Cowl fan-radiator Cowl fan-radiator	1	Upto VIN FA428918 From VIN FA428919
Dia 1	<b>esel</b> NRC3977 NTC3937	Cowl fan-radiator Cowl fan-radiator	1	Upto VIN FA389798 From VIN FA389799
Die 1	e <b>sel Turbo</b> NTC3937	Cowl fan-radiator	1	
<b>20</b>	<b>0Tdi</b> ESR335	Cowl fan-radiator	1	





604

### COOLING/HEATING



Model

DEFENDER 110 1987 onwards

UK and Europe Rest of World(Heavy Duty)

Page

AFLXAA2A

#### COOLING SYSTEM - FAN COWL


111.	Part No.	Description	Qty	Remarks
2	562979	Screw	5	Upto VIN FA389798
	562979	Screw	4	From VIN FA389799
3	WS600041L	Washer spring	5	Upto VIN FA389798
	WS600047L	Washer spring	4	From VIN FA389799
	595199	Washer plain	2	Diesel
		·		From VIN FA389799
	WS105001	Washer spring	2	200Tdi
	NH105041L	Nut	2	200Tdi
4	NRC7227	Ducting	1	4 Cylinder
5	NRC6430	Clip retaining	2	4 Cylinder
6	ETC4989	Cowl fan-engine	1	4 Cylinder
7	ETC4993	Mounting flexible	3	,
8	WA108051L	Washer plain	2	
9	WL108001L	Washer spring	6	
10	FN108041L	Nut	5	





605

### COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXAA3A

#### COOLING SYSTEM - RADIATOR HOSES


Ш.	Part No.	Description	Qty	Remarks
1	2.5 Petrol and Diesel NTC2029 ESR2125	Hose top Hose top	1	Upto VIN FA389798 From VIN FA389799
Ę	Diesel Turbo			
1	ESR2125	Hose top	1	
2	NRC7448	Clip retaining	1	
3	CN100508	Clip hose	2	
4	NTC3453	Hose bottom	1	
5	CN100508	Clip hose	2	
6	CN100308L	Clip hose	1	
7	NRC9726	Hose bleed	1	
	NTC2736	Hose bleed	1	Diesel turbo
8	AAU1979	Clip hose	2	





606

#### COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXAA3A

#### **COOLING SYSTEM - RADIATOR HOSES**


III. Part No.	Description	Qty	Remarks
	upto engine number 17H07705C		
NRC4842	Hose bottom	1	To engine
NRC4844	Hose bottom	1	To radiator
NRC4843	Tee piece	1	
CN100508	Clip hose	4	
NRC4837	Hose expansion tank	1	Diesel
NRC5503	Hose expansion tank	1	Petrol
CN100408	Clip hose	2	





607

#### COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXAA4A

#### COOLING SYSTEM - RADIATOR & INTERCOOLER HOSES - 200TDI


III.	Part No.	Description	Qty	Remarks
1 2 3 4 5 6 7	NTC4895 CN100508 ESR536 ESR1686 CN100508 CN100308 CN100308L NTC4898 CN100208L	Hose top Clip hose Hose bottom Hose bottom Clip hose Clip hose Clip hose Hose bleed Clip hose	1 2 1 1 2 1 1 1 1 2	Non Air Con Air Con
8 9	rbo to intercooler NTC5628 ESR299 ESR1906 ESR298 CN100608L	Pipe intercooler Hose elbow Hose elbow Clip hose	1 1 1 1	Upto VIN JA915341 From VIN JA915342
12 13 14 15	ercooler to manifold NTC5627 ESR299 ESR1906 ESR289 CN100608L ESR400	Pipe intercooler Hose elbow Hose elbow Glip hose Bracket bottom hose	1 1 1 1 4	Upto VIN JA915341 From VIN JA915342 Air con





608

#### COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXAA5A

#### COOLING SYSTEM - RADIATOR HOSES - V8


Ш.	Part No.	Description	Qty	Remarks
1	NRC5985	Hose top	1	Non air con Upto VIN FA428918
	NTC5686	Hose top	1	Non air con From VIN FA428919
	NRC9710	Hose top	1	Air con Upto VIN FA429127
	NTC5687	Hose top	1	Air con From VIN FA429128
2	NTC3543	Hose bottom	1	
3	CN100508	Clip hose	4	
4	NRC9726	Hose bleed	1	
	NTC2736	Hose bleed	1	When oil cooler fitted
5	AAU1979	Clip hose	2	
6	90575977	Hose bleed	1	Penthouse
7	AAU1979	Clip hose	2	





609

#### **COOLING/HEATING**



Model DEFENDER 110 1987 onwards
Page AFLXAA5A

#### COOLING SYSTEM - RADIATOR HOSES - V8


III. Part No.	Description	<b>Qty Remarks</b>
8 NRC2383 9 FS106201L 10 WA106041L 11 WM106001L 12 NH106041L	Clip retaining Flange screw Washer plain Washer spring Nut	1 1 1 1
Non air con 13 239600 14 FS108201L 15 WA108051L 16 WL108001L 17 FN108041L	Clip retaining Screw Plain Washer Spring Washer Nut	1 Penthouse bleed 1 Penthouse bleed 1 1





610

#### **COOLING/HEATING**



Model DEFENDER 110 1987 onwards
Page AFLXAG1A

#### ENGINE OIL COOLER - OIL COOLER AND MOUNTING FRAME


III. Part No.	Description	Qty	Remarks
4 Cylinder Petrol 1 NRC7741	Oil cooler	1	Upto VIN FA389798 Note(1)
<b>Diesel</b> 1 NRC7741	Oil cooler	1	Upto VIN FA389798 Note(1)
Diesel Turbo	Oil cooler		Note(2)
V8 - Non Air Con 1 NRC7741	Oil cooler	1	Upto VIN FA429127 Note(3)
<b>V8 - Air co</b> n 1 NRC8201	Oil cooler	1	Upto VIN FA429127 Note(3)





611

#### **COOLING/HEATING**



Model DEFENDER 110 1987 onwards
Page AFLXAG1A

#### ENGINE OIL COOLER - OIL COOLER AND MOUNTING FRAME


Note(1) From VIN FA389799 - Engine oil cooler is part of radiator Note(2) Diesel Turbo - Engine oil cooler is part of radiator Note(3) From VIN FA429128 - Engine oil cooler is part of radiator





612

#### COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXAG2A

#### GEARBOX OIL COOLER - COOLER AND FRAME - V8 LT77 GEARBOX


III.	Part No.	Description	Qty	Remarks
1	ESR488 ESR1554	Oil cooler Oil cooler	1	Upto JA922091 From JA922092
2	ESR489	Frame mounting	1	FIOIN JA922092
3	FS106167I	Screw	2	
4	SH106121L	Screw	2	
5	WA106041L	Washer plain	4	
6	NH106041L	Nut	4	
No	n Air Con			
7	NRC7459	U bolt	4	
8	WA106041L	Washer plain	8	
9	NH106041L	Nut	8	





613

### **COOLING/HEATING**



Model DEFENDER 110 1987 onwards
Page AFLXAI1A

#### ENGINE OIL COOLER - PIPES - NOTE(1)

III.	Part No.	Description	Qty	Remarks
1	NRC8507 NRC8509	Pipe assembly feed Pipe assembly feed	1	Air con
2	NRC8508	Pipe assembly return	1	All CON
	NRC8510	Pipe assembly return	i	Air con
3	NN106011	Nutsert	1	
4	594637	Clamp pipe	1	
5	FS106167L	Screw	1	
6	WL106001L	Washer spring	1	
7	NRC8618	Coupling	2	
8	ETC7398	Washer copper	2	

2.5 Petrol and Diesel - Upto VIN FA389798





614

### **COOLING/HEATING**

Model

DEFENDER 110 1987 onwards

Page

AFLXAI2A

**ENGINE OIL COOLER - PIPES** 

III. Part No.


Description

**Qty Remarks** 

Diesel Turbo and 200Tdi

2.	5 Petrol and Diesel	Nat Asp - From VIN FA	389799	
1	NTC2927	Pipe assembly feed	1	Upto VIN FA430172
	ESR71	Pipe assembly feed	1	From VIN FA430173
		•		Upto VINJA919831
	ESR280	Pipe assembly feed	1	From VIN FA430173
				Upto VIN JA919831
	ESR280	Pipe assembly feed	1	200Tdi
				Upto VIN JA919831
	ESR1912	Pipe assembly feed	1	From VIN JA919832
2	NTC2928	Pipe assembly return	1	Upto VIN FA430172
	ESR281	Pipe assembly return	1	From VIN FA430173
		•		Upto VIN JA919831
	ESR281	Pipe assembly return	1	200Tdi
		•		Upto VIN JA919831
	ESR1913	Pipe assembly return	1	From VIN JA919832
3	NTC3858	Adaptor radiator	2	Upto VIN JA919831
	ESR1262	Adaptor radiator	2	From VIN JA919832
4	NN106011	Nutsert	1	
5	594637	Clamp pipe	1	
	NTC6847	Clamp pipe	2	200Tdi
6	FS106167L	Screw	1	
7	WL106001L	Washer spring	1	
	WA106041L	Washer plain	2	200Tdi
	NY106041L	Nut nyloc	1	200Tdi
	568680	Cable tie	1	200Tdi
8	NRC8618	Coupling	2 2	
9	ETC7398	Washer copper	2	








615

# COOLING/HEATING



Model DEFENDER 110 1987 onwards

Page AFLXAI3A

#### ENGINE OIL COOLER - PIPES - V8 - UPTO VIN FA429127


III.	Part No.	Description	Qty	Remarks
1 2 3 4 5 6 7 8 9	ERC6720 ERC5923 TRS1114L ERC6722 ETC6812 PA105101 SH108301L ERC6890 ERR852 ERC3724 ERC3500	Adaptor assembly bypass Thermostat O ring Baseplate Baseplate Pin spring Screw Joint washer Joint washer Washer Nut tube	1 1 1 2 1 1 1 5 1 1 1	Upto VIN 322599 From VIN 322600 Upto VIN 322599 Upto VIN 322599 From VIN 322600
9 10	ERC3500 ERC6723	Nut tube Joint washer	1 1	





616

#### COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXAI3A

#### ENGINE OIL COOLER - PIPES - V8 - UPTO VIN FA429127


III.	Part No.	Description	Qty	Remarks
11	WA108051L	Plain washer	5	
12	WL108001L	Washer spring	5	
13	FN108041L	Nut	5	
14	NRC4162	Pipe flexible	2	
15	NRC5824	Pipe assembly feed	1	
	NRC8198	Pipe assembly feed	1	Air con
16	NRC5823	Pipe assembly	1	
	NRC8199	Pipe assembly return	1	Air con
17	NN106011	Nutsert	1	
18	594637	Clamp pipe	1	
19	FS106167L	Screw	1	
20	WL106001L	Washer spring	1	





617

#### **COOLING/HEATING**



Model DEFENDER 110 1987 onwards

Page AFLXAI4A

#### ENGINE OIL COOLER - PIPES - V8 - FROM VIN FA429128

ı	II.	Part No.	Description	Qty	Remarks
1	1	ESR399	Pipe assembly feed	1	Upto VIN JA922098
		ESR583	Pipe assembly feed	1	Upto VIN JA922098
		ESR1915	Pipe assembly feed	1	From VIN JA922099
2	2 .	NTC5624	Pipe assembly return	1	Except Note(1) Upto VIN JA922098
		ESR398	Pipe assembly return	1	Note(1) Upto VIN JA922098
		ESR1914	Pipe assembly return	1	From VIN JA922099
3	3	NTC3858	Adaptor radiator	2	Upto VIN JA922098
		ESR1262	Adaptor radiator	2	From VIN JA922099
4	1	NTC6847	Clamp pipe	2	
	5	FS106167L	Screw	1	
₹		WA106041L	Washer plain	1	
	7	NY106041L	Nut nyloc	1	
	3	ERC8501	Adaptor assembly filter	i	
	9	ERR852	Gasket	i .	
	10	ERC2226L	Adaptor screw	i	
	11	ETC9064	Coupling	ż	
		ETC9065	Washer copper	2	


Note(1) RHS vehicles with Gemmer power steering box from VIN HA469818





618

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXAI5A

#### GEARBOX OIL COOLER - PIPES - V8 LT77 GEARBOX

III.	Part No.	Description	Qty	Remarks
No	n Air Con			
1	ESR570	Pipe oil cooler RH front	1	Upto VIN JA922098
	ESR1919	Pipe oil cooler RH front	1	From VIN JA922099
2	ESR571	Pipe oil cooler LH front	1	Upto VIN JA922098
	ESR1920	Pipe oil cooler LH front	1	From VIN JA922099
Air	Con			
1	ESR530	Pipe oil cooler RH front	1	Upto VIN JA922098
	ESR1918	Pipe oil cooler RH front	1	From VIN JA922099
2	ESR531	Pipe oil cooler LH front	1	Upto VIN JA922098
	ESR1917	Pipe oil cooler LH front	1	From VIN JA922099
3	594637	Clip retaining	1	
	FS106167L	Screw	1	
	WA106041L	Washer plain	2	
	NN106011	Nut anchor	1	
7	ESR527	Pipe oil cooler rear	2	Upto VIN JA922098
	ESR1916	Pipe oil cooler rear	2	From VIN JA922099
	594637	Clip retaining	1	
	FS106201L	Screw	1	
	WA108051L	Washer plain	1	
	WA106041L	Washer plain	1	
	NTC5897	Bracket mounting	1	
	SH505081L	Screw	1	
14	WA106001L	Washer plain	2	






619

III. Part No.

#### COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXCA1A

#### COOLING SYSTEM - EXPANSION TANK

Petrol, Nat Asp Diesel,	Diesel Turbo		
4 Cylinder, All Variants 1 ESR2733 2 RTC3610 PCD100150 565540	Tank expansion Cap expansion tank-9psi Cap expansion tank-15psi Cap expansion tank-15psi	1 1 1	Upto LA932798 From LA932799 Diesel Turbo
V8 1 ESR2734 2 PCD100150	Tank expansion Cap expansion tank-15psi	1	
3 NRC6692 4 NRC5294 5 NRC5295	Carrier Strip carrier Strip carrier	1 2 2	
Fixings - Carrier to tanl 6 SH106207L FS106201L 7 NY106041L	K Screw Flange screw Nut nyloc	1 1 1	Upto FA389798 From FA389799

**Qty Remarks** 

Description






620

III. Part No.

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXCA1A

#### **COOLING SYSTEM - EXPANSION TANK**

Fixings - Carrier 8	to w	rheelarch Screw Washer plain Washer spring Nut Flange screw Washer plain Washer spring Nut	2 4 2 2 2 4 2 2	) )Upto )FA389798 ) ) )From )FA389799 )
Fixings - Carrier 12 SH106207L 13 WC106047 14 WL106007L FS106201L WC106041L WL106001L 15 NRC7133 16 564724 17 NRC1360 18 CP106121	to w	ring Screw Washer plain Washer spring Flange screw Washer plain Washer spring Nut plate Hose overflow Clip hose Clip retaining	1 1 1 1 1 1 1 1	)Upto )FA389798 ) )From )FA389799 )

Description


**Qty Remarks** 





621

## **COOLING/HEATING**



Model DEFENDER 110 1987 onwards
Page AFLXCC1A

#### **COOLING SYSTEM - EXPANSION TANK**

III. Part No.	Description	<b>Qty Remarks</b>
200TDI		
1 ESR63	Tank expansion	1
2 NTC7161	Cap expansion tank	i 15 psi
3 FS106167L	Screw	2
4 WA106041L	Washer plain	4
5 NH106041L	Nut	ż
6 ESR584	Bracket mounting	1
7 FS106167L	Screw	ż
8 WA106041L	Washer plain	2
9 NH106041L	Nut	1
10 NY106041L	Nul nyloc	i
	•	






622

## **COOLING/HEATING**

Model Page DEFENDER 110 1987 onwards

qe AFLXCC1B

#### COOLING SYSTEM - EXPANSION TANK



III.	Part No.	Description	<b>Qty Remarks</b>
30	OTOI		
1	ESR0063	Expansion tank	1
2	NH106041	Nut M6	3
3	SH106161	Screw M6	3
4	WA106041	Washer plain	5
5	ESR2343	Hose ejector/exp.tank	1
6	ESR2344	Hose radiator/ejector	1
7	ESR2345	Hose engine/ejector	i
8	ESR2346	Clip oetiker hose type	1
9	ESR2348	Pump ejector	i
10	ESR2349	Clip oetiker hose type	ż
11	CN100208	Clip hose	3
12	ESR2313	Bracket mounting	1
13	NH106041	Nut M6	i
14	SH106161	Screw M6	1
15	WA106041	Washer plain	i
16	NTC7161	Cap expansion tank-15psi	1






16

13

# DEFENDER 110 1987 onwards

623

#### **COOLING/HEATING**



Model DEFENDER 110 1987 onwards

Page AFLXGA1A

#### HEATING SYSTEM - HEATER

III. Part No.	Description	Qty	Remarks
4 Cylinder			
1 ŚTC456	Heater kit-RHS	1	Upto VIN HA900750
BTR1116	Heater assembly-RHS	1	From VIN HA900751 up to LA939975
BTR4318	Heater assembly - RHS	1	From MA939976
BTR1109	Heater assembly-LHS	1	Upto VIN HA900794
BTR1117	Heater assembly-LHS	1	From VIN HA900795 up to LA939975
BTR4317	Heater assembly - LHS	1	From MA939976
200TDI			
1 STC456	Heater kit-RHS	1	Upto VIN HA900808
BTR1116	Heater assembly-RHS	1	From VIN HA900809 up to LA939975
BTR4318	Heater assembly - RHS	1	From MA939976
BTR1109	Heater assembly-LHS	1	Upto VIN HA900795
BTR1117	Heater assembly-LHS	1	From VIN HA900796 up to LA939975
BTR4317	Heater assembly - LHS	1	From MA939976
V8			
1 STC456	Heater kit-RHS	1	Upto VIN HA900869
BTR1116	Heater assembly-RHS	1	From VIN HA900870 up to LA939975
BTR4318	Heater assembly - RHS	1	From MA939976
BTR1109	Heater assembly-LHS	1	Upto VIN HA900889
BTR1117	Heater assembly-LHS	1	From VIN HA900890 up to LA939975
BTR4317	Heater assembly - LHS	1	From MA939976





624


## COOLING/HEATING

Model Page DEFENDER 110 1987 onwards

AFLXGA1A

#### **HEATING SYSTEM - HEATER**

III. Part No.	Description	Qty Remarks
<b>300TDI</b> BTR4318	Hostor canombly DHC	4
BTR4317	Heater assembly - RHS Heater assembly - LHS	1
All variants		
2 STC952	Seal-heater to dash	1 RHS
STC953	Seal-heater to dash	1 LHS
3 SH108161L	Screw-to dash	2
4 RTC610	Washer plain	1
5 WL108001L	Washer spring	2
6 NN108021	Nutsert	2
7 FS106167L	Screw	2
8 WA106041L	Washer plain	2
9 WL106001L	Washer spring	2
10 NH106041L	Nut	2








625

## **COOLING/HEATING**



Model DEFENDER 110 1987 onwards
Page AFLXGA1A

#### HEATING SYSTEM - HEATER


III.	Part No.	Description	Qty	Remarks
11 12	MRC8378 MUC2417	Seal heater	1	
13	MUC2419	Valve dump Duct heater LH	<b>1</b> 1	RHS
14	MUC2418 MRC9998	Duct heater RH Seal Duct	1	LHS
	MRC9939	Finisher Grille LH	1	RHS
16	MRC9938 MRC9940	Finisher Grille RH Finisher Blanking RH	1	LHS RHS
17	MRC9941 AB608065L	Finisher Blanking LH Screw	1 14	LHS
18	AC608041L	Screw	4	
19 20	AJ608041 CZK619	Clip spire Nut lokut	9 9	





626

#### COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXGA2A

#### **HEATING SYSTEM - HEATER COMPONENTS**

III.	Part No.	Description	Qty	Remarks
1	AAP817	Matrix	1	Note(1)
	UTP1725	Matrix	1	Note(2)
2	AAP810	Volute assembly - RHS	1	Up to LA939975
	UTP1259	Volute & motor assy - RHS	1	From MA939976
	AAP811	Volute assembly - LHS	1	Up to LA939975
	UTP1258	Volute & motor assy - LHS	1	From MA939976
3	RTC4200	Motor and rotor - RHS	1	Up to LA939975
	RTC4201	Motor and rotor - LHS	1	Up to LA939975
	STC1207	Motor and rotor assembly	1	From MA939976
4	UTP1281	Harness and resistor	1	RHS
	UTP1282	Harness and resistor	1	LHS


Note(1) Note(2) For Heater assy with downward facing inlet/outlet pipes BTR1109 For Heater assy with horizontal inlet/outlet pipes STC456 BTR1116 BTR1117





627

## **COOLING/HEATING**



Model DEFENDER 110 1987 onwards
Page AFLXGA3A

#### **HEATING SYSTEM - HEATER CONTROLS**


111.	Part No.	Description	Qty	Remarks
Up 1	to LA939975 UTP1126	Control heater	1	RHS
2	UTP1125 AAP890 AAP876	Control heater Harness heater Cable control - outlet	1 1	LHS
1 2 3		Control assembly Control heater Harness heater control Cable control - outlet	1 1 1	RHS RHS
14 1 2 3 14	13H7343L BTR4434 AAP939 UTP1883 AAP876 13H7343L	Clip retaining  Control assembly  Control heater  Harness heater control  Cable control - outlet  Clip retaining	1 1 1 1 1	LHS LHS





628

## **COOLING/HEATING**



Model DEFENDER 110 1987 onwards
Page AFLXGA3A

#### **HEATING SYSTEM - HEATER CONTROLS**


III.	Part No.	Description	Qty	Remarks
4 5 6 7	ings - Control to cow SE105161L WA105001L 346924 347586 MTC2805 SG103084	Screw Washer plain Plate mounting and levers Plate mounting and levers Knob Screw	2 2 1 1 3	RHS LHS
9	MTC7737	Screw	2	
10 11	ings - Mounting plate SE808244 WA105004L MRC9922	t <b>o dash</b> Screw Washer plain Spacer	2 2 2	
13 14 15	MTC6194 13H7343L RTC5978	Cable control - blend Clip retaining Trunnion	1 2 2	
17 18	347939 BTR8736 566902 MTC6006 MTC6007	Cable control - distrib'n Cable control - distrib'n Trunnion Label Label	1 1 1 1	Up to LA939975 From MA939976





629

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXIA1A

#### HEATER SYSTEM - DEMISTERS AND OUTLET FLAPS


III.	Part No.	Description	Qty	Remarks
1	MRC9668	Nozzle RH	1	
	MXC3188	Nozzle RH	1	200Tdi Upto VIN JA906639
	BTR1600	Nozzle RH	1	200Tdi
				From VIN JA906640
1	MRC9669	Nozzle demist outlet	1	
	MXC3189	Nozzle LH	1	200Tdi
				Upto VIN JA906639
	BTR1599	Nozzle LH	1	200Tdi
_		_		From VIN JA906640
2	AB608047L	Screw	2	
3	WA105001	Washer plain	2	
	AB608054L	Screw	4	200Tdi
	AK608021	Nut spring	4	200Tdi
4	MTC6382	Tube flexible	2	
5	MRC7281	Grommet	2	
6	346894	Flaps heater outlet	1	Upto VIN HA905500
_	BTR1349	Flaps heater outlet	1	From VIN HA905501
7	346976	Spring	2	
8	395829	Grille outlet RH	1	
_	395830	Grille outlet LH	1	
9	MRC1525	Screw	4	






630

## COOLING/HEATING





Model DEFENDER 110 1987 onwards
Page AFLXIA2A

#### HEATING SYSTEM - HEATER PIPES - 4 CYL PETROL & DIESEL


111.	Part No.	Description	Qty	Remarks
Eng	gine feed and return NRC6306	Hose heater	2	
<b>He</b> 2	ater feed NRC6307 NRC6422	Pipe heater Pipe heater	1	RHS LHS
<b>Не</b> 3	ater return NRC6420 NRC6421	Pipe heater Pipe heater	1	RHS LHS
He 4	ater feed and return NRC6308	Hose heater	2	RHS Upto VIN HA900750
	NRC6309	Hose heater	2	LHS Upto VIN HA900794
5	BTR1134	Hose heater	2	RHS From VIN HA900751
	BTR1135	Hose heater	2	LHS From VIN HA900795





631


## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXIA2A

#### HEATING SYSTEM - HEATER PIPES - 4 CYL PETROL & DIESEL

III.	Part No.	Description	Qty	Remarks
Но	se fixings			
6	CN100258L	Clip hose	8	
7	NRC6417	Clamp pipe	1	Petrol
	NRC6418	Clamp pipe	1	Diesel
8	NRC6419	Clamp pipe	3	
9	SH106251L	Screw	2	
10	WL106001L	Washer spring	2	
11	NH106041L	Nut	2	








632

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXIA4A

#### **HEATING SYSTEM - HEATER PIPES - V8**


HI.	Part No.	Description	Qty	Remarks
En 1	gine feed NRC6311 NRC6352	Hose heater Hose heater	1	RHS LHS
<b>En</b> 2	gine return NRC6314 NRC6353	Hose heater Hose heater	1	RHS LHS
3 4 5	Ater feed and return NRC6902 NRC6312 NRC6313 NRC6313 BTR1136 BTR1137 CN100308I NRC8707	Pipe heater Pipe heater Hose heater Hose heater Hose heater Clip hose Bracket support	2 2 2 1 2 2 8	RHS LHS RHS Upto VIN HA900869 LHS Upto VIN HA900889 RHS From VIN HA900870 LHS From VIN HA900890 RHS
8 9 10 11 12	dings - Bracket to eng SH605071 WM600051L NRC6419 1H106301 WL106001 NH106041L	gine Screw Washer spring Clamp pipe Screw Washer spring Nut	1 1 1 1 1	RHS





633

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXIA3A

#### **HEATING SYSTEM - HEATER PIPES - 200TDI**


III. Part	No.	Description	Qty	Remarks
		Pipe heater Washer plain Nut	1 2 2	
<b>Heater</b> 4 ERR 5 BTR	1436	Hose heater Hose heater	1 1	RHS
6 BTR	982	Hose heater	1	Upto VIN HA900808 LHS
7 BTR	1130	Hose heater	1	Upto VIN HA900795 RHS From VIN HA900809
8 BTR	1131	Hose heater	1	LHS From VIN HA900796





634

#### COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXIA3A

#### HEATING SYSTEM - HEATER PIPES - 200TDI


III. Part No.	Description	Qty	Remarks
<b>Heater feed</b> 9 BTR447	Hose heater	1	RHS
10 BTR983	Hose heater	1	Upto VIN HA900808 LHS Upto VIN HA900795
11 BTR1132	Hose heater	1	RHS From VIN HA900809
12 BTR1133	Hose heater	1	LHS From VIN HA900796
13 CN100258L	Clip hose	6	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
14 BTR988	Clamp hose	1	
15 SH105121L	Screw	1	
16 WA105001L	Washer plain	1	
17 NY105041L	Nut nyloc	1	
18 NRC8332	Clip cable	1	





635

## **COOLING/HEATING**



Model DEFENDER 110 1987 onwards
Page AFLXIA3B

#### HEATING SYSTEM - HEATER PIPES - 300TDI

III. Part No.	Description	Qty Remarks
RHS 1 BTR6165 2 BTR6164	Hose heater inlet Hose heater return	1 1
LHS 3 BTR8396 4 BTR8395	Hose heater inlet Hose heater return	1 1
All variants 5 CN100258L 6 ERR4531 7 NRC8332	Clip hose Pipe assembly return Cable clip	4 1 1






636

III. Part No.

## COOLING/HEATING



Model DEFENDER 110 1987 onwards Page AFLXKA1A

AIR CONDITIONING - CONDENSER - RHS/LHS

	·	•	
<b>TDI CFC free</b> 1 AWR2335	Condenser		
Petrol & None Turk AWR1178	oo diesel CFC free Condenser	4	
AWITTO	Condenser	ı	
Petrol & None Turk	oo diesel		
RTC7416	Condenser	1	
2 RTC7417	Bracket support	4	
3 RTC7418	Grommet	4	
4 RTC7419	Bracket mounting	1	Lower
5 RTC7420 6 RTC7421	Bracket pilot	2	
6 RTC7421	Bracket mounting	1	Upper
7 RTC7422	Shroud fan	2 2 2 2	
8 RTC7423	Bracket support	2	
9 RTC7424	Motor fan	2	
10 RTC7425	Fan blade		
11 RTC7426	Receiver drier	1	
12 AEU3068	Switch high pressure	1	
13 RTC7427	Bracket support	1	
14 RTC7428	Clamp	2	
15 RTC7429	Hose assembly	1	
16 RTC7430	Hose discharge	1	
17 AEU3067	Valve discharge	1	
18 AEU3056	O ring	1	
19 AEU1626	O ring	2	0.3125 dia
20 AEU1627	O ring	2	0.4060 dia
21 MTC8500	Coupling	1	

Description


**Qty Remarks** 





637

#### COOLING/HEATING



Model DEFENDER 110 1987 onwards

Page

AFLXMA1A

#### AIR CONDITIONING - EVAPORATOR ASSEMBLY - RHS

III. Part No.	Description	Qty Remarks
Petrol & Non Turbo 1 AWR1168	Diesel RHS (CFC free) Evaporator	1
TDI RHS (CFC free) AWR1249	<b>134a gas</b> Evaporator	1
All variants MUC1663 2 MUC6050 3 MUC6037 4 MUC6038 5 MUC6042 6 MUC4375 7 MUC1682 8 MUC6040 9 MUC6053 10 MUC6054 11 MUC6055 12 MUC1675 13 MUC6052 14 MUC6056 15 RTC7470 16 STC760 17 STC761 18 STC762 19 STC948 20 MUC4860	Evaporator assembly Core heater Valve expansion Tube extension Thermostat Switch vacuum Adaptor Seal Wheel blower motor Spacer Lock nut Motor blower Seal Harness blower Clamp Housing blower motor Cover top evaporator Evaporator tube Seal	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1





638

## COOLING/HEATING

GROUP L

#### **MASTER INDEX**

INTRODUCTION PAGES ALPHABETICAL INDEX	PAGES 1 - 7 8 - 16	COOLING/HEATING	
ENGINE ENGINE ENGINE	17 - 66 67 - 119 120 - 166	COOLING/HEATING HEATER/COOLER ASSEMBLY - LHS	640 - 646
ENGINE ENGINE	167 - 209 210 - 245		
ENGINE GEARBOX	246 - 299 300 - 326		
GEARBOX GEARBOX TRANSFER BOX	327 - 344 345 - 359 360 - 378		
TRANSFER BOX AXLES AND SUSPENSION	379 - 397 398 - 444		
STEERING VEHICLE AND ENGINE CONTROLS BRAKES	445 - 471 472 - 486 487 - 517		
FUEL SYSTEM AND AIR CLEANER EXHAUST SYSTEM	518 - 579 580 - 593		
COOLING/HEATING COOLING/HEATING COOLING/HEATING	594 - 637 638 - 641 642 - 649	·	
COOLING/HEATING COOLING/HEATING	650 - 655 656 - 666		
BODY ELECTRICAL BODY AND CHASSIS INTERIOR TRIM	667 - 740 741 - 909 910 - 955		
SEATS STOWAGE	956 - 1036 1037 - 1046		
ACCESSORIES - PAINTS NUMERICAL INDEX	1047 - 1074 1076 - 1151		





639

#### COOLING/HEATING

#### GROUP L

#### COOLING/HEATING

#### COOLING/HEATING

 HEATER PIPES - 4 CYLINDER - LHS
 652

 HEATER PIPES - TDI - LHS
 653

 HEATER PIPES - V8 - RHS
 654


 HEATER PIPES - V8 - LHS
 655





640

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page ADLXMA2A


III. Part No.	Description	Qty Remarks
1 RTC7588 2 RTC7456 3 RTC7433 4 RTC7434 5 RTC7436    AWR1177    AWR1242 6 AEU1213 7 AEU1214 8 RTC7458 9 RTC7457 10 AEU3055 11 RTC7439 12 RTC7454 13 RTC7454 13 RTC7455 14 RTC7471 16 RTC7472 17 RTC7473 18 RTC7473 19 MUC4358 RTC7452 MUC1661	Heater/Cooler Assembly Resistor Core heater Thermostat Evaporator Evaporator(cfc free) Evaporator(cfc free) Valve expansion Clamp Pipe assembly Coupling Valve service Hose assembly Relay Harness blower Switch vacuum Seal Seal Cover Seal-to duct Adaptor R4 comp/rotolock Ring rotolock Seal-to dash	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1





641

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page ADLXMA3A

III. Part No.	Description	Qty Remarks
1 RTC7440	Motor blower	1
2 RTC7468	Mounting motor	1
3 RTC7441	Wheel blower motor	1
4 RTC7442	Housing blower motor	1
5 RTC7469	Bracket support	3
6 RTC7470	Clamp	1
7 RTC7446	Seal-bulkhead	1
RTC7474	Seal-firewall	1
2 MUC6050	Core heater	1
3 MUC6037	Valve expansion	1
4 MUC6038	Tube extension	1
5 MUC6042	Thermostat	1
6 MUC4375	Switch vacuum	1
7 MUC1682	Adaptor	1
8 MUC6040	Seal	1
9 MUC6053	Wheel blower motor	1
10 MUC6054	Spacer	1
11 MUC6055	Lock nut	1
12 MUC1675	Motor blower	1
13 MUC6052	Seal	1
14 MUC6056	Harness blower	1
15 RTC7470	Clamp	1
16 STC760	Housing blower motor	1
17 STC761	Cover top evaporator	1
18 STC762	Cover rotor evaporator	1
19 STC948	Evaporator tube	1
20 MUC4860	Seal	1





642

## **COOLING/HEATING**

#### **MASTER INDEX**

#### GROUP L

	PAGES	COOLING/LICATING	
INTRODUCTION PAGES	1 - 7	COOLING/HEATING	
ALPHABETICAL INDEX	8 - 16		
ENGINE	17 - 66	OCOLING (IFATING	
ENGINE	67 - 119	COOLING/HEATING	
ENGINE	120 - 166	RADIATOR	596 - 598
ENGINE	167 - 209	RADIATOR, INTERCOOLER & OIL COOLER - 300TDI	599 - 602
ENGINE	210 - 245	FAN COWL	603 - 604
ENGINE	246 - 299	RADIATOR HOSES	605 - 606
GEARBOX	300 - 326	RADIATOR & INTERCOOLER HOSES - 200TDI	607
GEARBOX	327 - 344	RADIATOR HOSES - V8	608 - 609
GEARBOX	345 - 359	OIL COOLER AND MOUNTING FRAME	610 - 611
TRANSFER BOX	360 - 378	COOLER AND FRAME - V8 LT77 GEARBOX	612
TRANSFER BOX	379 - 397	PIPES - NOTE(1)	613
AXLES AND SUSPENSION	379 - 397	PIPES	614
STEERING		PIPES - V8 - UPTO VIN FA429127	615 - 616
VEHICLE AND ENGINE CONTROLS	445 - 471	PIPES - V8 - FROM VIN FA429128	617
BRAKES	472 - 486	PIPES - V8 LT77 GEARBOX	618
FUEL SYSTEM AND AIR CLEANER	487 - 517	EXPANSION TANK	619 - 622
EXHAUST SYSTEM	518 - 579	HEATER	623 - 625
	580 - 593	HEATER COMPONENTS	626
COOLING/HEATING	594 - 637	HEATER CONTROLS	627 - 628
COOLING/HEATING	638 - 641	DEMISTERS AND OUTLET FLAPS	629
COOLING/HEATING	642 - 649	HEATER PIPES - 4 CYL PETROL 630 DIESEL	630
COOLING/HEATING	650 - 655	HEATER PIPES - 4 CYL PETROL 631 DIESEL	
COOLING/HEATING	656 - 666	HEATER PIPES - V8	631
BODY ELECTRICAL	667 - 740	HEATER PIPES - 200TDI	632
BODY AND CHASSIS	741 - 909	HEATER PIPES - 300TDI	633 - 634
INTERIOR TRIM	910 - 955	CONDENSER - RHS/LHS	635
SEATS	956 - 1036	EVAPORATOR ASSEMBLY - RHS	636
STOWAGE	1037 - 1046	LVAPORATOR ASSEMBLY - KHS	637
ACCESSORIES - PAINTS	1047 - 1074		
NUMERICAL INDEX	1076 - 1151		





643

#### **COOLING/HEATING**

GROUP L

COOLING/HEATING

GROUP L

#### COOLING/HEATING


COOLINIO/UTATINO		FRESH AIR DUCT - RHS	0-0
COOLING/HEATING FLUID SYSTEM - RHS	647	PLENUM 659 DEFROSTERS - RHS FACIA PANEL ASSEMBLY - RHS	658 659 660
VACUUM PIPES & RESERVOIR - RHS/LHS HEATER PIPES - 4 CYLINDER - RHS	648 649	FRESH AIR DUCT - LHS AIR DUCT INSULATION - LHS	661 662
		HEATER CONTROLS - LHS PLENUM CHAMBER - LHS	663 664
		FACIA PANEL - LHS DEMISTER AND FLAPS	665 666





644

#### **COOLING/HEATING**



Model DEFENDER 110 1987 onwards
Page AFLXMA2A


III. Part No.	Description	Qty Remarks
1 RTC7588	Heater/Cooler Assembly	1
2 RTC7456	Resistor	1
3 RTC7433	Core heater	1
4 RTC7434	Thermostat	1
5 RTC7436	Evaporator	1
6 AEU1213	Valve expansion	1
7 AEU1214	Clamp	1
8 RTC7458	Pipe assembly	1
9 RTC7457	Coupling	1
10 AEU3055	Valve service	1
11 RTC7439	Hose assembly	1
12 RTC7454	Relay	1
13 RTC7455	Harness blower	1





645

## **COOLING/HEATING**



Model DEFENDER 110 1987 onwards
Page AFLXMA2A


III. Part No.	Description	Qty Remarks
14 RTC7414 15 RTC7471 16 RTC7472 17 RTC7473	Switch vacuum Seal Seal Cover	1 2 1 1
Evaporator to duct 18 RTC7453 19 MUC4358 RTC7452	Seal Adaptor Ring rotolock	1 1 -R4 comp/rotolock 2
Evaporator to dash MUC1661 AWR1173	Seal Seal kit	1 .





646

#### COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXMA3A


Ш.	Part No.	Description	Qty Remarks
1	RTC7440	Motor blower	1
2	RTC7468	Mounting motor	1
3	RTC7441	Wheel blower motor	1
4	RTC7442	Housing blower motor	1
5	RTC7469	Bracket support	3
6	RTC7470	Clamp	1
7	RTC7446	Seal bulkhead	1
	RTC7474	Seal firewall	1





647

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXPA1A

#### AIR CONDITIONING - FLUID SYSTEM - RHS


III. Part No.	Description	Qty Remarks
1 MUC4875 2 AEU3055 3 MUC4874 4 MUC4872 5 RTC7457 6 RTC7452 7 MUC4358 AEU1628 AEU1626 AEU1627 AEU3056	Hose suction Valve service Seal Hose liquid Fitting aeroquip Ring rotolock Adaptor O ring O ring O ring O ring	1 1 1 1 2 2 2 1 R4 comp/rotolock 2 1 1 3





648

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXPA2A

#### AIR CONDITIONING - VACUUM PIPES & RESERVOIR - RHS/LHS

III.	Part No.	Description	Qty	Remarks
1	MUC1679	Tank vacuum	1	
2	MUC4878	Hose vacuum	1	30" x 0.109375"
3		Hose vacuum	1	5" - Note(1)
4		Hose vacuum	1	20" - Note(1)
5	MUC4455	Tee piece	2	` '
6	MUC4866	Hose vacuum	1	10" x 0.21875
7		Hose vacuum	1	10" - Note(1)
8		Hose vacuum	1	1" - Note(1)
9	MUC4865	Tee piece	1	
10	MUC1671	Harness vacuum	1	
11	MUC4871	Harness vacuum	1	
	ATU1041	Clamp hose	8	

Note(1) Use MUC4878 = 30" x 0.109375"






649

## **COOLING/HEATING**

Model Page DEFENDER 110 1987 onwards

AFLXPC1A

#### AIR CONDITIONING - HEATER PIPES - 4 CYLINDER - RHS



Ш.	Part No.	Description	Qty	Remarks
1	NRC6306	Hose heater	2	
2	CN100308L	Clip hose	2	
3	NRC6307	Pipe heater-feed	1	
4	NRC6420	Pipe heater-return	1	
5	CN100258L	Clip hose	8	
6	BTR213	Hose engine to valve	ĭ	UptoMA939975
	BTR9400	Hose engine to valve	i	FromMA939976
7	NRC8346	Valve water control	1	
8	ERC3964	Hose valve to heater	1	UptoMA939975
	BTR9401	Hose valve to heater	1	FromMA939976
9	BTR214	Hose heater-return	1	UptoMA939975
	BTR9402	Hose heater return	1	FromMA939976
10	NRC6417	Clip retaining	1	Petrol
	NRC6418	Clip retaining	1	Diesel
11	NRC6419	Clamp pipe	1	2.0001
12	SH106251L	Screw	1	
13	WL106001L	Washer spring	1	
14	NH106041L	Nut	1	
15	ESR3301	Strap retaining	1	





650

#### COOLING/HEATING

#### **MASTER INDEX**

GROUP L

INTRODUCTION PAGES	PAGES 1 - 7	COOLING/HEATING	
ALPHABETICAL INDEX	8 - 16		
ENGINE	17 - 66	OOOL IN OUR EATING	
ENGINE	67 - 119	COOLING/HEATING HEATER/COOLER ASSEMBLY - LHS	640 - 646
ENGINE	120 - 166	HEATEH/COULER ASSEMBLT - LITS	040 - 040
ENGINE	167 - 209		
ENGINE	210 - 245		
ENGINE	246 - 299		
GEARBOX	300 - 326		
GEARBOX	327 - 344		
GEARBOX	345 - 359		
TRANSFER BOX	360 - 378		
TRANSFER BOX	379 - 397		
AXLES AND SUSPENSION	398 - 444		
STEERING	445 - 471		
VEHICLE AND ENGINE CONTROLS	472 - 486		
BRAKES	487 - 517		
FUEL SYSTEM AND AIR CLEANER	518 - 579		
EXHAUST SYSTEM	580 - 593		
COOLING/HEATING	594 - 637		
COOLING/HEATING	638 - 641		
COOLING/HEATING	642 - 649		
COOLING/HEATING	650 - 655		
COOLING/HEATING	656 - 666 667 - 740		
BODY ELECTRICAL	667 - 740 741 - 909		
BODY AND CHASSIS	910 - 955		
INTERIOR TRIM	956 - 1036		
SEATS	1037 - 1046		
STOWAGE PAINTS	1047 - 1074		
ACCESSORIES - PAINTS NUMERICAL INDEX	1076 - 1151		
NUMERICAL INDEX	1070 1101		





651

## COOLING/HEATING

#### GROUP L

#### COOLING/HEATING

#### COOLING/HEATING


HEATER PIPES - 4 CYLINDER - LHS	652
HEATER PIPES - TDI - LHS	653
HEATER PIPES - V8 - RHS	654
HEATER PIPES - V8 - LHS	655





652

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page ADLXPC2A

### AIR CONDITIONING - HEATER PIPES - 4 CYLINDER - LHS


III. Part No.	Description	Qty Remarks
1 NRC6306	Hose heater	2
2 CN100258L	Clip hose	4
3 NRC8245	Pipe heater	2
4 CN100258L	Clip hose	6
5 ERC3964	Hose heater-feed	1
6 NRC8346	Valve water control	1
7 NRC8347	Hose heater-feed	1
8 NRC8247	Hose heater-return	1
9 NRC8248	Bracket mounting	1
10 594637	Clamp pipe	1
11 FS106201L	Flange screw	1
12 WL106001L	Washer spring	1
13 NH106041L	Nut	1
14 ESR3301	Strap retaining	1





653

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page ADLXPC3A

### AIR CONDITIONING - HEATER PIPES - TDI - LHS


i	I. Part No.	Description	Qty	Remarks
1		Pipe heater	1	
2 3	WA110065	Washer plain	2	
3	NT110041L	Nut	2 2	
4	ERR1436	Hose heater-return	1	
5		Hose heater return	1	UptoMA939975
	AWR2334	Hose heater return	1	FromMA939976
6	BTR985	Hose - valve to heater	1	UptoMA939975
	AWR2333	Hose - valve to heater	1	FromMA939976
7		Hose - engine to valve	1	UptoMA939975
	AWR2332	Hose - engine to valve	1	FromMA939976
8		Valve water control	1	
9		Clip hose	8	
	0 BTR987	Bracket support	1	
	1 SH105121L	Screw	2	
	2 MRC9851	Washer nylon	2	
	3 NY105041L	Nut	2	
	4 BTR988	Clamp pipe	2	
	5 SH105121L	Screw	2 2 2 2 2 2	
	6 WA105001L	Washer plain	2	
	7 NY105041L	Nut	2	
1	8 ESR3301	Strap retaining	1	





654

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page ADLXPC4A

### AIR CONDITIONING - HEATER PIPES - V8 - RHS

III.	Part No.	Description	Qty Remarks
1	NRC6314	Hose heater	2
2	CN100308L	Clip hose	4
3	NRC6902	Pipe heater	2
4	ERC3964	Hose heater-feed	1
5	CN100258L	Clip hose	10
6	NRC8346	Valve water control	1
7	NTC1212	Hose heater-feed	1
8	NRC6308	Hose heater-return	1
9	NRC6903	Bracket support	1
10	NRC6419	Clamp pipe	1
11	SH106301L	Screw	1
12	WL106001L	Washer spring	1
13	NH106041L	Nut	1
14	ESR3301	Strap retaining	1





655

## COOLING/HEATING

Model

DEFENDER 110 1987 onwards

Page

ADLXPC5A

#### AIR CONDITIONING - HEATER PIPES - V8 - LHS

3
10 5
11 12 15

III.	Part No.	Description	Qty Remarks
11 12 13 14 15	NRC9098 NRC6353 CN100308L NRC9091 NTC1090 ERC3964 CN100258L NRC8346 NTC1089 NTC1088 NRC1088 NRC8620 594637 SH106301L WL106001L NH106041L	Hose heater-feed Hose heater-return Clip hose Pipe heater-feed Pipe heater-feed Clip hose Valve water control Hose heater-feed Hose heater-feed Hose heater-feed Clip hose Valve water control Hose heater-feed Hose heater-return Bracket support Clamp pipe Screw Washer spring Nut	1 1 4 1 1 1 7 7 1 1 1 1 1 1 1
16	ESR3301	Strap retaining	ı





656

## **COOLING/HEATING**

### **MASTER INDEX**

#### GROUP L

	PAGES	COOLINGATING	
INTRODUCTION PAGES	1 - 7	COOLING/HEATING	
ALPHABETICAL INDEX	8 - 16		
ENGINE	17 - 66	COOLING/LICATING	
ENGINE	67 - 119	COOLING/HEATING	500 500
ENGINE	120 - 166	RADIATOR	596 - 598
ENGINE	167 - 209	RADIATOR, INTERCOOLER & OIL COOLER - 300TDI	599 - 602
ENGINE	210 - 245	FAN COWL	603 - 604
ENGINE	246 - 299	RADIATOR HOSES	605 - 606
GEARBOX	300 - 326	RADIATOR & INTERCOOLER HOSES - 200TDI	607
GEARBOX	327 - 344	RADIATOR HOSES - V8	608 - 609
GEARBOX	345 - 359	OIL COOLER AND MOUNTING FRAME	610 - 611
TRANSFER BOX	360 - 378	COOLER AND FRAME - V8 LT77 GEARBOX	612
TRANSFER BOX	379 - 397	PIPES - NOTE(1)	613
AXLES AND SUSPENSION	398 - 444	PIPES	614
STEERING	445 - 471	PIPES - V8 - UPTO VIN FA429127	615 - 616
VEHICLE AND ENGINE CONTROLS	472 - 486	PIPES - V8 - FROM VIN FA429128	617
BRAKES	487 - 517	PIPES - V8 LT77 GEARBOX	618
	518 - 579	EXPANSION TANK	619 - 622
FUEL SYSTEM AND AIR CLEANER		HEATER	623 - 625
EXHAUST SYSTEM	580 - 593	HEATER COMPONENTS	626
COOLING/HEATING	594 - 637	HEATER CONTROLS	627 - 628
COOLING/HEATING	638 - 641	DEMISTERS AND OUTLET FLAPS	.629
COOLING/HEATING	642 - 649	HEATER PIPES - 4 CYL PETROL 630 DIESEL	630
COOLING/HEATING	650 - 655	HEATER PIPES - 4 CYL PETROL 631 DIESEL	631
COOLING/HEATING	656 - 666	HEATER PIPES - V8	632
BODY ELECTRICAL	667 - 740	HEATER PIPES - 200TDI	633 - 634
BODY AND CHASSIS	741 - 909	HEATER PIPES - 300TDI	635
INTERIOR TRIM	910 - 955	CONDENSER - RHS/LHS	636
SEATS	956 - 1036	EVAPORATOR ASSEMBLY - RHS	637
STOWAGE	1037 - 1046	The Control of the Co	557
ACCESSORIES - PAINTS	1047 - 1074		
NUMERICAL INDEX	1076 - 1151		





657

## COOLING/HEATING

GROUP L

#### COOLING/HEATING

GROUP L

#### COOLING/HEATING

COOLING/HEATING FLUID SYSTEM - RHS VACUUM PIPES & RESERVOIR - RHS/LHS HEATER PIPES - 4 CYLINDER - RHS	647 648 649	COOLING/HEATING FRESH AIR DUCT - RHS PLENUM 659 DEFROSTERS - RHS FACIA PANEL ASSEMBLY - RHS FRESH AIR DUCT - LHS AIR DUCT INSULATION - LHS HEATER CONTROLS - LHS PLENUM CHAMBER - LHS FACIA PANEL - LHS	658 659 660 661 662 663 664 665
		DEMISTER AND FLAPS	666





658

## COOLING/HEATING


Model

DEFENDER 110 1987 onwards

Page

AFLXRA1A






111	. Part No.	Description	Qty	Remarks
1	MUC1668	Duct air	1	
2	MUC4884	Motor vacuum	1	
3	RTC7467	Motor vacuum	1	
4	MUC4883	Seal - duct to wing top	1	
5	MUC4886	Seal - duct to evaporator	1	
6	MUC4888	Seal - air duct to dash	1	Upto EA332911
	MWC4860	Seal - air duct to dash		From EA332912
7	RTC7470	Clamp	1	
		•		





659

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXRA2A

### AIR CONDITIONING - PLENUM & DEFROSTERS - RHS


III.	Part No.	Description	Qty	Remarks
1 2 3 4 5 6 7 8	MUC1665 AEU4002 MUC6021 MUC4882 MUC4881 MUC4891 MUC1673 MUC4892 MUC1674 AWR1247	Plenum chamber assembly Motor vacuum Seal Seal RH Seal LH Adaptor Duct LH Hose Duct RH Duct RH	1 2 1 1 1 1 1 1	NLS UptoMA939975 FromMA939976
10 11	AB606021L MUC3695	Screw Pad insulation	22 1	





660

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXRA3A

### AIR CONDITIONING - FACIA PANEL ASSEMBLY - RHS

111.	Part No.	Description	Qty	Remarks
1	MUC1667	Facia assembly	1	
2	MUC6001	Panel	1	UptoMA939975
	AWR1245	Panel	1	FromMA939976
3	AEU4002	Motor vacuum	2	110111111111111000010
4	MUC1666	Control assembly	1	UptoMA939975
	AWR1666	Control assembly	1	FromMA939976
5	MUC6011	Knob	1	
6	MUC6012	Switch clutch	1	
7	MUC6013	Switch fresh air	1	
8	573289	Bulb	1	
9	MUC4880	Louvre	4	
10	MUC1669	Duct assembly	1	
11	RTC7411	Louvre	1	
12	MUC4895	Hose - duct to plenum	1	Upto EA332911
	MXC3418	Hose - duct to plenum	1	From EA332912
13	MXC3357	Adaptor duct	1	From EA332912
14	MXC3358	Adaptor plenum	1	From EA332912
15	MUC1670	Finisher	1	
16	MUC1680	Cable control	1	
17	RTC7465	Finisher	1	





661

## **COOLING/HEATING**


Model Page AIR CO

el DEFENDER 110 1987 onwards
AFLXRA4A

### AIR CONDITIONING - FRESH AIR DUCT - LHS

III.	Part No.	Description	Qty	Remarks
1 2 3 4 5 6 7 8 9	MTC5571 RTC7461 RTC7460 RTC7459 AEU4002 MUC4455 RTC7470 ATU1041	Duct air Seal - duct to wing top Seal - duct to evaporator Seal - air duct to dash Motor vacuum Hose vacuum Hose vacuum Hose vacuum Tee piece Clamp Clamp Clamp hose	1 1 1 1 1 1 1 1 1 1 8	5" Note(1) 12" Note(1) 9" Note(1)
	A101041	Clamp nose	0	

Note(1) Use MUC4878 = 30" x 0.109375"







662

## COOLING/HEATING

Model Page

DEFENDER 110 1987 onwards

AFLXRA5A

### AIR CONDITIONING - AIR DUCT INSULATION - LHS

3	
c;	
2	4

III.	Part No.	Description	Qty Remarks
2	MUC1657 MUC1658 MUC1659 MUC1660	Insulation top Insulation bottom Insulation outer Insulation inner	1 1 1





663

## COOLING/HEATING




DEFENDER 110 1987 onwards

AFLXRA6A

### AIR CONDITIONING - HEATER CONTROLS - LHS

3
39976
39976








664

## **COOLING/HEATING**



Model DEFENDER 110 1987 onwards

Page AFLXRA7A

### AIR CONDITIONING - PLENUM CHAMBER - LHS

111.	Part No.	Description	Qty	Remarks
1	RTC7408	Plenum chamber assembly	1	
	AWR1174	Plenum extension	1	FromMA939976
2	RTC7462	Seal outlet	1	
3	RTC7463	Seal outlet	1	
4	RTC7464	Seal inlet	1	
5	RTC7409	Hose	1	
6	RTC7415	Panel closing	1	UptoMA939975
	AWR1448	Panel closing	1	FromMA939976
7	AEU4002	Motor vacuum	1	
8	AB606021	Screw	22	


Plenum chamber to toe box Spacer A/R





665

## **COOLING/HEATING**



Model DEFENDER 110 1987 onwards
Page AFLXRA8A

### AIR CONDITIONING - FACIA PANEL - LHS


III. Part No.	Description	<b>Qty Remarks</b>
1 RTC7450 2 AEU4000 3 AEU4001 AWR1169	Facia assembly Plate instruction Louvre Louvre	1 1 5 5
Facia to front plan	te Screw	2
5 ACU5431 6 AB608051	Nut lokut Screw	2 2 2 2
7 WC105001	Washer plain	2
Facia panel end f		
8 MTC5581 9 AW606124	Finisher	1
10 WA104004	Screw	1
11 ACU5431	Washer plain Nut lokut	1
12 RTC7410	Finisher assembly	1
AWR1170	Finisher assembly	1 UptoMA939975
13 RTC7411	Louvre	1 FromMA939976
14 79086	Rivet rokut	1
15 MTC7516	Finisher	i
16 RTC7465	Finisher	1
17 RTC7412	Switch illuminated	1
RTC7413	Bulb	1





666

## COOLING/HEATING



Model DEFENDER 110 1987 onwards
Page AFLXRA9A

### AIR CONDITIONING - DEMISTER AND FLAPS

Ш.	Part No.	Description	Qty	Remarks
1	NRC9668 MXC3188	Nozzle RH Nozzle RH	1 1	LHS 200Tdi LHS Upto VIN JA906639
	BTR1600	Nozzle RH	1	200Tdi LHS From VIN JA906640
1	NRC9669 MXC3189	Nozzle LH Nozzle LH	1	LHS 200Tdi LHS Upto VIN JA906639
	BTR1599	Nozzle LH	1	200Tdi LHS From VIN JA906640
2 3	AB608047L WA105001	Screw Washer plain	2 2	LHS LHS
Fix 4 5 6 7 8 9	AB608054L RTC3745 AK608021 MRC7279 MRC7281 MUC1139 BTR1347 MUC3278 BTR1348 MTC5578 346796 395829 395830 MRC1525	Screw Nut lokut Nut spring Flexible Tube Grommet Outlet flaps assy LHS Outlet flaps assy LHS Outlet flaps assy RHS Outlet flaps assy RHS Actuating bar Spring Grille outlet RH Grille outlet LH Screw	41 122 1 1 1 1 1 2 1 4	RH nozzle RH nozzle LHS LHS Upto HA905497 NLA use BTR1347 From HA905498 Upto JA908189 NLA use BTR1348 From JA908190

